



- B1 Purge connector
- B2 Cable gland M20
- B3 PE connector
- B4 Receiver/transmitter front panel
- B5 Laser connector M23 -20
- B6 Laser connector M23 +20
- B7 Cable gland M25

- B8 Cable gland PG21
- B9 Cable gland M20
- B10 HMI button
- B11 HMI green LED
- B12 HMI red LED
- B13 HMI front panel
- B14 HMI window